

FIG. 1

LOAD
BALANCING
MODULE

33 34

32 Edit My Fiery List 30

Auto Search Manual

Available Devices Help Add

Name	Device Name	IP Address
Fiery1	Engine1	10.10.78.17

36 38 31 37

▼

My Fiery

Name	Device Name	IP Address
Fiery2	Engine2	10.11.143.56
Fiery3	Engine3	10.10.78.25

35

Modify Remove 40

OK Cancel Add

FIG. 3

Automatic Load-Balance Server Version 1.0




FIG. 4

